



SC-106 REV 1 FLUSH SOLVENT FOR FLUSHING/CLEANING MIX EQUIPMENT LINES AND DISPENSING COMPONENTS

SC-106 REV 1 Flush Solvent was formulated to be used in BJB's meter mix dispense equipment for purging and cleaning feed lines, dispensing guns, and mixing chambers. It is excellent for use during operations of fast reacting, two-component polyurethane systems. SC-106 REV 1 exhibits good solvent cleaning strength and may be used as a parts cleaner or immersion bath with most components.

CAUTION:

Always wipe remaining SC-106 REV 1 off any parts and flush residual fluid out of cleaned equipment. Solvent blends such as SC-106 REV 1 may not be compatible with other manufacturer's equipment components. A test should be done to confirm compatibility. Do not use this product as a storage fluid. BJB recommends flushing equipment with SC-107 Storage Fluid if the equipment will not be used for any period after cleaning with SC-106 REV 1.

STORAGE:

Store at ambient temperatures, 65-80°F (18-27°C). Unopened containers will have a shelf life of 12 months from date of shipment when properly stored at recommended temperatures. Purge opened containers with dry nitrogen before re-sealing.

PACKAGING

One Gallon	7.2 lbs.
5-Gallon Pail	36 lbs.

HEALTH AND SAFETY:

Use in a well-ventilated area. Avoid contact with skin using protective gloves and protective clothing. Repeated or prolonged contact on the skin may cause an allergic reaction. In case of a spill, use absorbent material to clean up and dispose of in accordance with local, state and federal regulations. Eye protection is extremely important. Always use approved safety glasses or goggles when handling this product.

IF CONTACT OCCURS:

- Skin:** Immediately wash with soap and water. Remove contaminated clothing and launder before reuse. It is *not* recommended to remove resin from skin with solvents. Solvents only increase contact and dry skin. Seek qualified medical attention if allergic reactions occur.
- Eyes:** Immediately flush with water for at least 15 minutes. Call a physician.
- Ingestion:** If swallowed, call a physician immediately. Remove stomach contents by gastric suction or induce vomiting only as directed by medical personnel. Never give anything by mouth to an unconscious person.

Refer to the Material Safety Data Sheet before using this product.

NON-WARRANTY "Except for a warranty that materials substantially comply with the data presented in Manufacturer's latest bulletin describing the product (the basis for this substantial compliance is to be determined by the standard quality control tests generally performed by Manufacturer), all materials are sold "AS IS" and without any warranty express or implied as to merchantability, fitness for a particular purpose, patent, trademark or copyright infringement, or as to any other matter. In no event shall Manufacturer's liability for damages exceed Manufacturer's sale price of the particular quantity with respect to which damages are claimed."